



The following table identifies the appropriate model of the VL-ENCL-5 Development Enclosure for use with different VersaLogic computers.

<i>Model</i>	<i>Accommodates</i>
VL-ENCL-5a	VL-EBX-12 Cobra VL-EPIC-2 Gecko
VL-ENCL-5b	EPM-CPU-3 Bobcat EPM-CPU-10 Jaguar VL-EPM-32 Cheetah
VL-ENCL-5c	VL-EBX-11 Python VL-EBX-22 Sidewinder VL-EPICs-36 Komodo VL-EPM-4 Lynx VL-EPM-5 Puma VL-EPM-14 Cougar VL-EPM-15 Manx
VL-ENCL-5d	VL-EPMs-21 Ocelot

Related Documents:

- [VL-ENCL-5 Reference Manual](#) - Contains general installation instructions.
- [VT1631 - VL-ENCL-5a Assembly Instructions for the VL-EBX-12 Cobra](#)
- [VT1632 - VL-ENCL-5a Assembly Instructions for the VL-EPIC-2 Gecko](#)
- [VT1633 - VL-ENCL-5b Assembly Instructions for the EPM-CPU-3 Bobcat](#)
- [VT1634 - VL-ENCL-5b Assembly Instructions for the EPM-CPU-10 Jaguar](#)
- [VT1635 - VL-ENCL-5c Assembly Instructions for the VL-EPM-4 Lynx](#)
- [VT1636 - VL-ENCL-5c Assembly Instructions for the VL-EPM-5 Puma](#)

###